

ELECTRIC CHAIN

COFFING[®] HOISTS EC SERIES

Before installing hoist, fill in the information below.

Model Number _____

Serial No. _____

Purchase Date _____

Please provide Serial Number when ordering parts.

CAPACITIES:

1/4 TON

1/2 TON

1 TON

2 TON

3 TON

**Follow all instructions and warnings for inspecting,
maintaining and operating this hoist.**

The use of any hoist presents some risk of personal injury or property damage. That risk is greatly increased if proper instructions and warnings are not followed. Before using this hoist, each operator should become thoroughly familiar with all warnings, instructions and recommendations in this manual. **Retain this manual for future reference and use.**

Forward this manual to the hoist operator. Failure to operate equipment as directed in manual may cause injury.

Columbus McKinnon Corporation
205 Crosspoint Parkway
Getzville, NY 14068



COFFING HOIST PARTS AND SERVICES ARE AVAILABLE IN THE UNITED STATES AND IN CANADA

As a COFFING Hoist and Trolley user you are assured of reliable repair and parts services through a network of Master Parts Depots and Service Centers that are strategically located in the United States and Canada. These facilities have been selected on the basis of their demonstrated ability to handle all parts and repair requirements promptly and efficiently. To quickly obtain the name of the Master Parts Depot or Service Center located nearest you, call (800) 888-0985. Fax: (716) 689-5644.

LAS PIEZAS Y REPARACIONES DE LOS POLIPASTOS DE COFFING ESTÁN ASEGURADAS EN ESTADOS UNIDOS Y CANADÁ

Como usuario de un polipasto y carro de COFFING le aseguramos cualquier reparación o la disponibilidad de cualquier pieza de repuesto a través de una red de almacenes de piezas de repuesto y centros de servicio situados estratégicamente en Estados Unidos y Canadá. Estas instalaciones se han seleccionado en base a su capacidad demostrada en la reparación de equipos y suministro de piezas de repuesto de forma rápida y eficaz. Para obtener la dirección del almacén de piezas de repuesto o del centro de servicio más cercano, llame al teléfono (800) 888-0985. Fax: (716) 689-5644 (sólo en Estados Unidos y Canadá).

LE SERVICE DE RÉPARATION ET DE PIÈCES POUR PALANS COFFING EST DISPONIBLE AUX ÉTATS-UNIS ET AU CANADA

Soyez assurés qu'en temps d'utilisateur de palan et treuil COFFING, d'un service de réparation et de pièces fiable par l'entremise d'un réseau de Centres de service et de Dépôts de pièces maîtresses qui sont stratégiquement situés aux États-Unis et au Canada. Ces établissements ont été sélectionnés sur une base de leur habileté démontrée à s'occuper promptement et efficacement des besoins de réparation de pièces. Appelez le (800) 888-0985, Fax: (716) 689-5644 pour obtenir rapidement le nom du dépôt de pièces maîtresses ou du centre de service situé le plus près.

WARNING

Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in death or serious injury. To avoid such a potentially hazardous situation, **THE OPERATOR SHALL:**

- a. **NOT** operate a damaged, malfunctioning or unusually performing hoist.
- b. **NOT** operate the hoist until you have thoroughly read and understood this Operating, Maintenance and Parts Manual.
- c. **NOT** operate a hoist which has been modified without the manufacturer's approval or without certification that it is in conformity with ANSI/AMSE B30 volumes.
- d. **NOT** lift more than rated load for the hoist.
- e. **NOT** use hoist with twisted, kinked, damaged, or worn load chain.
- f. **NOT** use the hoist to lift, support, or transport people.
- g. **NOT** lift loads over people.
- h. **NOT** operate a hoist unless all persons are and remain clear of the supported load.
- i. **NOT** operate unless load is centered under hoist.
- j. **NOT** attempt to lengthen the load chain or repair damaged load chain.
- k. Protect the hoist's load chain from weld splatter or other damaging contaminants.
- l. **NOT** operate hoist when it is restricted from forming a straight line from hook to hook in the direction of loading.
- m. **NOT** use load chain as a sling, or wrap chain around load.
- n. **NOT** apply the load to the tip of the hook or to the hook latch.
- o. **NOT** apply load unless load chain is properly seated in the chain sprocket(s).
- p. **NOT** apply load if bearing prevents equal loading on all load supporting chains.
- q. **NOT** operate beyond the limits of the load chain travel.
- r. **NOT** leave load supported by the hoist unattended unless specific precautions have been taken.
- s. **NOT** allow the load chain or hook to be used as an electrical or welding ground.
- t. **NOT** allow the load chain or hook to be touched by a live welding electrode.
- u. **NOT** remove or obscure the warnings on the hoist.
- v. **NOT** operate a hoist on which the safety placards or decals are missing or illegible.
- w. **NOT** operate a hoist unless it has been securely attached to a suitable support.
- x. **NOT** operate a hoist unless load slings or other approved single attachments are properly sized and seated in the hook saddle.
- y. Take up slack carefully - make sure load is balanced and load holding action is secure before continuing.
- z. Shut down a hoist that malfunctions or performs unusually and report such malfunction.
- aa. Make sure hoist limit switches function properly.
- ab. Warn personnel of an approaching load.

CAUTION

Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. To avoid such a potentially hazardous situation, **THE OPERATOR SHALL:**

- a. Maintain firm footing or be otherwise secured when operating the hoist.
- b. Check brake function by tensioning the hoist prior to each lift operation.
- c. Use hook latches. Latches are to retain slings, chains, etc. under slack conditions only.
- d. Make sure the hook latches are closed and not supporting any parts of the load.
- e. Make sure the load is free to move and will clear all obstructions.
- f. Avoid swinging the load or hook.
- g. Make sure hook travel is in the same direction as shown on the controls.
- h. Inspect the hoist regularly, replace damaged or worn parts, and keep appropriate records of maintenance.
- i. Use CM Hoists recommended parts when repairing the unit.
- j. Lubricate load chain per hoist manufacturer's recommendations.
- k. **NOT** use the hoist's overload limiting clutch to measure load.
- l. **NOT** use limit switches as routine operating stops. They are emergency devices only.
- m. **NOT** allow your attention to be diverted from operating the hoist.
- n. **NOT** allow the hoist to be subjected to sharp contact with other hoists, structures, or objects through misuse.
- o. **NOT** adjust or repair the hoist unless qualified to perform such adjustments or repairs.

SAFETY PRECAUTIONS

Each Electric Chain Hoist is built in accordance with the specifications contained herein and at the time of manufacture complies with our interpretation of applicable sections of "American Society of Mechanical Engineers Code (ASME) B30.16 "Overhead Hoists," the National Electrical Code (ANSI/NFPA 70) and the Occupational Safety and Health Act (OSHA). Since OSHA states the National Electrical Code applies to all electric hoists, installers are required to provide current overload protection and grounding on the branch circuit section in keeping with the code. Check each installation for compliance with the application, operation and maintenance sections of these articles.

The safety laws for elevators, lifting of people and for dumbwaiters specify construction details that are not incorporated into the hoists. For such applications, refer to the requirements of applicable state and local codes, and the American National Safety Code for elevators, dumbwaiters, escalators and moving walks (ASME A17.1). Columbus McKinnon Corporation cannot be responsible for applications other than those for which COFFING equipment is intended. DO NOT use for guided loads.

*Copies of this standard can be obtained from ASME Order Department, 22 Law Drive, PO Box 2300, Fairfield, NJ 07007-2300, U.S.A., www.asme.org, 800-843-2763.



THIS SYMBOL POINTS OUT IMPORTANT SAFETY INSTRUCTIONS WHICH IF NOT FOLLOWED COULD ENDANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURSELF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL AND ANY PROVIDED WITH THE EQUIPMENT BEFORE ATTEMPTING TO OPERATE YOUR HOIST.

HOIST SAFETY IS UP TO YOU...

WARNING

DO NOT LIFT MORE THAN RATED LOAD.

CHOOSE THE RIGHT HOIST FOR THE JOB...

Choose a hoist with the capacity for the job. Know the capacities of your hoists and the weight of your loads. Then match them.

The application, the size and type of load, the attachments to be used and the period of use must also be taken into consideration in selecting the right hoist for the job.

Remember, the hoist was designed to ease our burden and carelessness not only endangers the operator, but in many cases, a valuable load.



WARNING

DO NOT OPERATE DAMAGED OR MALFUNCTIONING HOIST.

DO NOT OPERATE WITH TWISTED, KINKED, OR DAMAGED CHAIN.

INSPECT

All hoists should be visually inspected before use, in addition to regular, periodic maintenance inspections.

Inspect hoists for operations warning notices and legibility.

Deficiencies should be noted and brought to the attention of supervisors. Be sure defective hoists are tagged and taken out of service until repairs are made.

Under no circumstances should you operate a malfunctioning hoist.

Check for gouged, twisted, distorted links and foreign material. Do not operate hoists with twisted, kinked, or damaged chain links.

Load chain should be properly lubricated.

Hooks that are bent, worn, or whose openings are enlarged beyond normal throat opening should not be used. If latch does not engage throat opening of hook, hoist should be taken out of service.

Chains should be checked for deposits of foreign material which may be carried into the hoist mechanism.

Check brake for evidence of slippage under load.



WARNING

DO NOT PULL AT AN ANGLE. BE SURE HOIST AND LOAD ARE IN A STRAIGHT LINE.

DO NOT USE LOAD CHAIN AS A SLING.

USE HOIST PROPERLY


Be sure hoist is solidly held in the uppermost part of the support hook arc.

Be sure hoist and load are in a straight line. Do not pull at an angle.

Be sure load is hooked securely. Do not tip load the hook. Do not load hook latch. Hook latch is to prevent detachment of load under slack chain conditions only.

Do not use load chain as a sling. Such usage damages the chain and lower hook.

Do not operate with hoist head resting against any object. Lift the load gently. Do not jerk it.



WARNING


DO NOT LIFT PEOPLE OR LOADS OVER PEOPLE

LIFT PROPERLY

Do not lift co-workers with a hoist.

Make sure everyone is clear of the load when you lift.

Do not remove or obscure operational warning notices.



MAINTAIN PROPERLY

CLEANING

Hoists should be kept clean and free of dust, dirt, moisture, etc., which will in any way affect the operation or safety of the equipment.

LUBRICATION

Chain should be properly lubricated.

AFTER REPAIRS

Carefully operate the hoist before returning it to full service.



VIOLATIONS OF ANY OF THE WARNINGS LISTED MAY RESULT IN SERIOUS PERSONAL INJURY TO THE OPERATOR OR NEARBY PERSONNEL BY NATURE OF RELEASED LOAD OR BROKEN HOIST COMPONENTS.

FOREWORD

This manual contains important information to help you properly install, operate and maintain your hoist for maximum performance, economy and safety.

Please study its contents thoroughly before putting your hoist into operation. By practicing correct operating procedures and by carrying out the recommended preventive maintenance suggestions, you will experience long, dependable and safe service. After you have completely familiarized yourself with the contents of this manual, we recommend that you carefully file it for future reference.

The information herein is directed to the proper use, care and maintenance of the hoist and does not comprise a handbook on the broad subject of rigging.

Rigging can be defined as the process of lifting and moving heavy loads using hoists and other mechanical equipment. Skill acquired through specialized experience and study is essential to safe rigging operations. For rigging information, we recommend consulting a standard textbook on the subject.

TABLE OF CONTENTS

Master Parts Depots And Service Centers	2
Safety Precautions	3
Foreword	5

INTRODUCTION

General Information	6
Safety Standards	6
Hoist Construction and Features	6
Basic Hoist Data	6
Application Information	6
Warranty	6

INSTALLATION

Safety Notes	6
Hanging the Hoist	6
Power Supply Connection	7
Vent Plug	7
Chain Lubrication	7
Testing	7
Trolley Installation	7
Chain Container Installation	9

OPERATION

General	10
Safety Notes	10
Handling the Load	10
Overload Limiting Protection	10

INSPECTION

General	11
Frequent Inspection	11
Periodic Inspection	11
Load Brake Function Check	13
Chain Inspection	13
Hook Throat Opening	14

MAINTENANCE AND REPEAT

General	15
Limit Switch Adjustment	15
Motor Brake Adjustment	15
Top Suspension Removal and Replacement	15
Chain Replacement	16
Lubrication	16

TROUBLESHOOTING

General	18
---------------	----

WIRING

Wiring Diagrams	19
Voltage Conversion	19

REPAIR PARTS

General	24
How to Use	24
Hoist Model Number and Serial Number	24

Recommended Spare Parts	45
-------------------------------	----

LIST OF TABLES

TABLE	DESCRIPTION	PAGE
1-1	Basic Hoist Data	6
2-1	Washer Chart	8
4-1	Maximum Allowable Hook Hook Throat Opening	14
5-1	Recommended Lubrication Schedule	17
6-1	Troubleshooting	18

LIST OF ILLUSTRATIONS

FIG.	DESCRIPTION	PAGE
2-1	CTA Trolley	7
2-2	Lug Mounted Plain Trolley	9
2-3	Chain Container	9
4-1	Recommended Inspection and Maintenance Check List	12
4-2	Recommended Inspector's Report	13
4-3	Load Brake Function	13
4-4	Link Wear	13
5-1	Limit Switch Adjustment	15
5-2	Motor Brake Adjustment	15
5-3	Chaining Hoist	16
5-4	Chaining and Suspension Diagrams	17
7-1	115V, 230V - 3 Phase, 1-Speed Hoist	20
7-2	230V, 460V - 3 Phase, 1-Speed Hoist	21
7-3	208V, 380V 575V - 3 Phase, 1-Speed Hoist	22
7-4	208V, 230V, 460V, 575V - 3 Phase, 2-Speed Hoist	23
8-1	Suspension Assemblies	25
8-2	Basic Hoist	26
8-3A	Motor Parts (One Speed)	28
8-3B	Motor Parts (Two Speed)	29
8-4A	Parts List for Electrical Parts for 115/230V - 1-Phase Models	30
8-4B	Parts List for Electrical Parts for 3-Phase Models	31
8-5	Transmission	32
8-6	Chaining Parts	34
8-7A	Push Button (Single Speed Hoists)	35
8-7B	Push Button (Two Speed Hoists)	36
8-8A	Parts List for Limit Switch Assembly	37
8-8B	Parts List for Long Lift Limit Switch Assembly	38
8-9	Motor Brake Parts	39
8-10A	1/4 Ton & 1/2 Ton Models	41
8-10B	1 Ton Models	41
8-10C	Double Chain Models	41
8-10D	Triple Chain Models	41
8-11	Chain Container Assemblies (1/4 Ton & 1/2 Ton Models)	42
8-12	CTA Plain Trolley Assembly	43
8-13	CTA Geared Trolley Assembly	44

SECTION I INTRODUCTION

1-1. GENERAL INFORMATION

This manual provides information for the safe operation and maintenance of Coffing® EC-1 Series Hoists. All persons operating or maintaining these hoists should be familiar with the information contained herein. Adherence to the precautions, procedures, and maintenance practices described should ensure long reliable operation. Suggestions for improvements to this manual are solicited.

CAUTION

To safeguard against the possibility of personal injury or property damage, follow the recommendations and instructions of this manual. This manual contains important information for the correct installation, operation, and maintenance of this equipment. All persons involved in the installation, operation, and maintenance of this equipment should be thoroughly familiar with the contents of this manual. Keep this manual for reference and further use.

WARNING

To avoid personal injury:

Do not use the equipment shown in this manual to lift, support, or otherwise transport people, or to suspend unattended loads over people.

1-2. SAFETY STANDARDS

All persons concerned with the installation, operation, inspection and maintenance of these hoists are urged to read ASME B30.16. That Standard contains valuable guidelines concerning practices designed to minimize hazards associated with the use of overhead hoisting equipment. ASME B30.16 also contains detailed procedures for establishing hoist inspection and maintenance programs and can be of significant assistance in maintaining compliance with OSHA regulations.

1-3. HOIST CONSTRUCTION AND FEATURES

Strong, lightweight aluminum alloy die castings provide a compact, protective enclosure for the mechanical and electrical components of Coffing EC-1 Series Hoists. Heat treated alloy steel gearing operates in an oil bath to provide the most reliable lubrication and effective heat dissipation.

EC-1 Series Hoists incorporate the following features:

- Overload limiting clutch.
- Completely independent mechanical and electrical brakes.
- Adjustable limit switches.
- Tough, nylon weather resistant pushbutton stations.
- Steel strain cable inside pushbutton cord.
- Transformer isolated, low-voltage pushbutton controls.
- Quick voltage conversion on dual-voltage units.

TABLE 1-1. BASIC HOIST DATA

Model No.	Rated Load (lb.)	Lift Speed at Rated Load (ft. per min.)	Motor HP
EC-0516	500	16	1/4
EC-0532	500	32	1/2
EC-0564	500	64	1
EC-1009	1000	9	1/4
EC-1016	1000	16	1/2
EC-1032	1000	32	1
EC-2004	2000	4	1/4
EC-2008	2000	8	1/2
EC-2012	2000	12	1
EC-2016	2000	16	1
EC-4006	4000	6	1
EC-4008	4000	8	1
EC-6005	6000	5	1

1-4. BASIC HOIST DATA

The basic hoist models covered by this manual are listed in Table 1-1.

1-5. APPLICATION INFORMATION

This hoist is intended for general industrial use in the lifting and transporting of freely suspended material loads within its rated load. Prior to installation and operation, the user should review his application for abnormal environmental or handling conditions and to observe the applicable recommendations as follows:

- Adverse Environmental Conditions. Do not use the hoist in areas containing flammable vapors, liquids, gases or any combustible dusts or fibers. Refer to Article 500 of The National Electric Code. Do not use this hoist in highly corrosive, abrasive or wet environments. Do not use this hoist in applications involving extended exposure to ambient temperatures below -10°F or above 130°F.
- Lifting of Hazardous Loads. This hoist is not recommended for use in lifting or transporting hazardous loads or materials which could cause widespread damage if dropped. The lifting of loads which could explode or create chemical or radioactive contamination if dropped requires fail-safe redundant supporting devices which are not incorporated into this hoist.
- Lifting of Guided Loads. This hoist must not be used in the lifting of guided loads, including dumbwaiters and non-riding elevators. Such applications require additional protective devices which are not incorporated into this hoist. Refer to your state and local regulations governing the requirements for elevator and dumbwaiter installations.

1-6. WARRANTY

Every hoist is thoroughly inspected and tested prior to shipment from the factory. Should any problems develop, return the complete hoist prepaid to your nearest Coffing Authorized Warranty Repair Station. If inspection reveals that the problem is caused by defective workmanship or material, repairs will be made without charge and the hoist will be returned, transportation prepaid.

This warranty does not apply where: (1) deterioration is caused by normal wear, abuse, improper or inadequate power supply, eccentric or side loading, overloading, chemical or abrasive actions, improper maintenance or excessive heat; (2) problems resulted from repairs, modifications or alterations made by persons other than factory or Coffing Authorized Warranty Repair Station personnel; (3) the hoist has been abused or damaged as a result of an accident; (4) repair parts or accessories other than those supplied by Coffing are used on the hoist. Equipment and accessories not of the seller's manufacture are warranted only to the extent that they are warranted by the manufacturer. EXCEPT AS STATED HEREIN, COFFING MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

SECTION II INSTALLATION

2-1. SAFETY NOTES

- Inspect the hoist for any evidence of shipping damage or loose parts.
- The supporting structure and load attaching devices should have a load rating at least equal to that of the hoist.
- This hoist is not suitable for use in uncovered outdoor locations or areas containing explosive dust, vapors or gases.
- The installation area must provide safe operating conditions for the operator, including sufficient room for the operator and other personnel to stand clear of the load at all times.
- In areas where slack chain hanging from the hoist may create a hazard, use a chain container (see Figure 2-2).

2-2. HANGING THE HOIST

Hook mounted hoists can be used with a variety of trolleys or stationary hangers. It is recommended that a hand-gear or motorized trolley be used when the pulling effort required to move the hoist exceeds 100 pounds or when the application requires frequent movement of the hoist.

- Make sure that the hook latch closes after hanging the hoist.
- The standard top hook is restrained from rotation by a plate and two screws. The hook can be made to swivel freely by removing the plate, or can be rotated 90° and fixed in that position.
- See Figure 2-1 for instructions on adjusting lug- mounted plain trolleys.
- Refer to Coffing Motorized Trolley Operating and Maintenance Instructions manual for motorized trolley installation instructions.

2-3. POWER SUPPLY CONNECTION

- Disconnect power before making connections.
- Voltage supplied to the hoist should be within plus or minus 10% of the voltage specified for the hoist. Hoists are tagged at the factory with a tag indicating the voltage for which the hoist is wired. Standard single phase hoists are convertible from 115 to 230 volts. Standard single speed, three phase hoists are convertible from 460 volts to 230 volts. See the Wiring section (paragraph 7-1) for voltage conversion instructions.
- National Electrical Code (ANSI C2) and local electrical codes should be consulted and proper disconnects, branch circuit protectors, and wiring provided.
- Power cables furnished with the hoist have a green colored ground wire which must be securely connected to the electrical system ground.
- When installing a three-phase hoist, make only temporary connections at the power line. Push the "UP" button and observe the direction of the hook. If it raises, the phasing is correct and permanent connections may be made at the power line. If the load block lowers when the "UP" button is pushed, release the button immediately since the limit switches will not operate to protect the hoist from over-travel. Reverse the red and black wires at the power line connection to correct the hook direction.

CAUTION

Do not change connections in the hoist or the pushbutton assembly.

2-4. VENT PLUG

A pressure relief plug (Item 24, Figure 8-2) is provided which will vent excess pressure from the transmission housing.

2-5. CHAIN LUBRICATION

The hoist chain should be liberally oiled before placing the hoist into operation. For lubrication instructions, see paragraph 5-6a.

2-6. TESTING

- Before placing the hoist into operation, check for proper limit switch operation. Push the "UP" button and verify that the hook block stops at least 2 inches from the bottom of the hoist. Run the hoist down to its lower limit. At least 12 links of chain should remain on the slack end. If either switch is not correct, adjust according to the procedure outlined in paragraph 5-2.

NOTE

The upper and lower limit switches are factory set to provide the maximum allowable hook travel. This travel adjustment should not be increased. However, the switches may be adjusted to stop the hook sooner at either end of its travel.

- Attach a light load to the hook and check the hoist for proper operation. The load should stop without noticeable drift when the pushbutton is released. Increase the load to near rated load. The hoist should still lift the load without hesitation and stop with no more than one inch drift.

2-7. TROLLEY INSTALLATION

For Motorized, Lug Mounted and Plain Trolley configurations refer to manual included with the Trolley.

- Motorized Trolley - manual p/n ECMT680-7
- Lug Mounted Trolley - manual p/n CTA698-1
- Plain Trolley - manual p/n CTA698-1

CT-Series Trolleys can be mounted on American Standard I-beams From 6 to 18 inches high. Adjustment for different beam dimensions is accomplished with proper placement of spacer washers as described in below paragraph 2-7.

- I-Beam Adjustment** - Adjustment for I-Beam sizes and tolerances is accomplished by locating the spacer washers as shown in Figure 2-1. Normal placement of washers is given in Table 2-2. Refer to Table 2-1 for identification of part names and numbers.

BEAM MANUFACTURING TOLERANCES ALLOW WIDE VARIATIONS FROM HANDBOOK FLANGE WIDTHS, AND SLIGHT CHANGES TO THE RECOMMENDED WASHER DISTRIBUTION MAY BE NECESSARY TO SUIT SPECIFIC INSTALLATIONS.

The particular beam on which your hoist is to be installed should be measured and trolley spacer washers adjusted to achieve a clearance of 3/32" to 1/8".

- Periodic Inspection** - The trolley should be inspected periodically for evidence of excess wear or overload. Parts should be replaced as required.
- Lubrication** - Trolley wheels are equipped with sealed, lifetime lubricated, precision ball bearings which should not require lubrication for the normal service of the trolley.

See Figure 8-12 and 8-13 for assembly details.




FIGURE 2-1. CTA TROLLEY

STANDARD BEAM Size & Weight	Flange Width	Location A H4210 (Thin)	Location B H4209 (Thick)	Location C H4209 (Thick)	Location D H4209 (Thick)	Location E H4210 (Thin)	Location F H4209 (Thick)
6" x 12.5#	3.332	1	13	10	9	1	14
6" x 17.3#	3.565	2	12	11	10	0	13
7" x 15.3#	3.662	0	12	11	10	2	13
7" x 20.0#	3.860	1	11	12	11	1	12
8" x 18.4#	4.001	1	11	12	12	1	11
8" x 23.0#	4.171	1	10	13	12	1	11
10" x 25.4#	4.661	1	8	15	14	1	9
10" x 35.0#	4.944	1	7	16	15	1	8
12" x 31.8#	5.000	0	7	16	15	2	8
12" x 35.0#	5.078	1	7	16	16	1	7
12" x 40.8#	5.252	1	6	17	16	1	7
12" x 50.0#	5.477	1	5	18	17	1	6
15" x 42.9#	5.501	1	5	18	17	1	6
15" x 50.0#	5.640	1	5	18	18	1	5
18" x 54.7#	6.001	1	3	20	19	1	4
18" x 70.0#	6.251	2	2	21	20	0	3
20" x 66.0#	6.255	2	2	21	20	0	3
24" x 80.0#	7.000	1	0	23	23	1	0
WIDE FLANGE BEAM Size & Weight	Flange Width	Location A H4210 (Thin)	Location B H4209 (Thick)	Location C H4209 (Thick)	Location D H4209 (Thick)	Location E H4210 (Thin)	Location F H4209 (Thick)
5" x 16.0#	5.000	0	7	16	15	2	8
5" x 19.0#	5.030	1	7	16	16	1	7
6" x 9.0#	3.940	1	11	12	12	1	11
6" x 12.0#	4.000	2	10	13	12	0	11
6" x 15.0#	5.990	1	3	20	19	1	4
6" x 16.0#	4.030	2	10	13	12	0	11
6" x 20.0#	6.020	2	3	20	20	0	3
6" x 25.0#	6.080	1	3	20	20	1	3
8" x 10.0#	3.940	1	11	12	12	1	11
8" x 13.0#	4.000	2	10	13	12	0	11
8" x 15.0#	4.015	2	10	13	12	0	11
8" x 18.0#	5.250	2	6	17	17	0	6
8" x 21.0#	5.270	1	6	17	17	1	6
8" x 24.0#	6.495	1	1	22	21	1	2
8" x 28.0#	6.535	1	1	22	21	1	2
10" x 12.0#	3.960	1	11	12	12	1	11
10" x 15.0#	4.000	2	10	13	12	0	11
10" x 17.0#	4.010	2	10	13	12	0	11
10" x 19.0#	4.020	2	10	13	12	0	11
10" x 22.0#	5.750	2	4	19	19	0	4
10" x 26.0#	5.770	2	4	19	19	0	4
10" x 30.0#	5.810	1	4	19	19	1	4
12" x 14.0#	3.970	1	11	12	12	1	11
12" x 16.0#	3.990	2	10	13	12	0	11
12" x 19.0#	4.005	2	10	13	12	0	11
12" x 22.0#	4.030	2	10	13	12	0	11
12" x 26.0#	6.490	1	1	22	21	1	2
12" x 30.0#	6.520	1	1	22	21	1	2
12" x 35.0#	6.560	2	1	22	22	0	1
14" x 22.0#	5.000	1	7	16	16	1	7
14" x 26.0#	5.025	1	7	16	16	1	7
14" x 30.0#	6.730	0	1	22	22	2	1
14" x 34.0#	6.745	0	1	22	22	2	1
14" x 38.0#	6.770	1	0	23	22	1	1
16" x 26.0#	5.500	2	5	18	18	0	5
16" x 31.0#	5.525	0	5	18	17	2	6
16" x 36.0#	6.985	0	0	22	23	2	0
16" x 40.0#	6.995	0	0	22	23	2	0
18" x 35.0#	6.000	1	3	20	19	1	4
18" x 40.0#	6.015	2	3	20	20	0	3
18" x 46.0#	6.060	0	3	20	19	2	4
21" x 44.0#	6.500	1	1	22	21	1	2
21" x 50.0#	6.530	1	1	22	21	1	2
21" x 57.0#	6.555	2	1	22	22	0	1
24" x 55.0#	7.005	0	0	23	23	2	0

TABLE 2-1. WASHER CHART




FIGURE 2-2. LUG-MOUNTED PLAIN TROLLEYS




FIGURE 2-3. CHAIN CONTAINER

2-8. CHAIN CONTAINER INSTALLATION

- Operate hoist in "down" direction until it is stopped by the limit switch. Disconnect the slack end of the chain from the hoist by using a small screwdriver to slide the spring-load pin to the left. At least 8 inches of chain should hang from the hoist. If less than 8 inches of slack chain is present, readjust lower limit switch using the procedures detailed in paragraph 5-2.
- Slide the spring-loaded pin aside and slip the mounting arm into the slot until the pin fits through the hole in the plate (see Figure 2-2). Be sure pin passes completely through plate and into the opposite housing.
- Use the two hex washer head screws provided to fasten the two remaining hanger chains into the notches on the lower edges of the hoist housing.
- Be sure the end of the chain is started into the container. Run hoist up until the hook block is even with the bottom of the chain container.
- Reset upper limit switch at this position (see procedure, paragraph 5-2) to prevent the possibility of raising a load into the chain container.

SECTION III OPERATION

3-1. GENERAL

This section presents information concerning the proper operation of the Coffing Electric Chain Hoist. It is not intended to serve as a handbook on rigging. Rigging, the process of moving heavy loads using mechanical devices, requires special knowledge and equipment. For information on the safe use of slings and similar rigging gear, users are urged to consult a textbook on rigging.

3-1. SAFETY NOTES

- a. Inspect the hoist for any sign of loose, broken, or malfunctioning parts (see Section IV). Any malfunctioning hoist should be tagged as “out of order: and removed from service until the defect is corrected.
- b. Before starting the hoist, the operator should be certain that all personnel are clear.
- c. Do not lift more than the rated load of the hoist.
- d. Do not lift people or loads over people.
- e. Avoid jogging controls or quick reversals of suspended loads.
- f. Do not leave a suspended load unattended.
- g. The operator should have a clear view of the load anytime it is moving and should be sure that the load does not contact any obstructions.
- h. Read ASME B30.16 Safety Standard for Overhead Hoists.

3-3. HANDLING THE LOAD

- a. Align hoist directly over load. Avoid side pull.
- b. The hoist chain should not be wrapped around the load. Use proper slings.
- c. Be sure there are no twists in the load chain as it enters the hoist.

CAUTION

This condition should be constantly checked on double or triple chain hoists because it is possible for the load block to be “capsized” or flipped over one or more times, putting twist in the chain. The presence of twist may not be obvious when the hook block is in the lowered position but can cause serious chain binding when the hook block is in its fully raised position.

- d. Bring the hook into engagement with the load and make sure it is well seated before proceeding to lift the load. On multiple reeved hoists, be sure that the load is equalized on all supporting chains.
- e. Lift the load just clear of its supports and stop the hoist to check for proper brake operation.
- f. Avoid letting the hook or load swing excessively while moving a trolley suspended hoist.

3-4. OVERLOAD LIMITING PROTECTION

This hoist is equipped with a factory-calibrated overload limiting clutch. While the overload limiting clutch will protect the hoist from damaging overloads, it will not ensure that a load is within the rated capacity of the hoist. If the load exceeds the lifting capability of the overload clutch, the hoist will not lift the load, but the motor will continue to run as long as the “UP” button is pressed. Repeated attempts to lift an excessive load will overheat the overload clutch and cause permanent damage to the clutch.

CAUTION

The overload limiting clutch is an emergency protective device and should not be used to measure the maximum load to be lifted, or to sense the overload imposed by a constrained load. While the overload limiting clutch will protect the hoist from damaging overloads, it will not ensure that a load is within the rated capacity of the hoist.

SECTION IV INSPECTION

4-1. GENERAL

A scheduled inspection routine should be established for this hoist based upon severity of use and environmental conditions. Some inspections should be made frequently (daily to monthly) and others periodically (monthly to yearly). It is suggested that an Inspection and Maintenance Check List and an Inspector's Report similar to those shown in Figures 4-1 and 4-2 be used and filed for reference. All inspections should be made by a designated inspector. Special inspections should be made after any significant repairs or any situation causing suspicion that the hoist may have been damaged. Any hoist which has been removed from service for an extended time should receive an inspection as described under Periodic Inspections. ASME B30.16, Safety Standard for Overhead Hoists, provides guidelines for hoist operation and inspection.

CAUTION

Any unsafe condition disclosed by any inspection must be corrected before operation of the hoist is resumed.

4-2. FREQUENT INSPECTION

- a. Check pushbutton station, brake and limit switches for proper operation.
- b. Check hooks for deformation, chemical damage or cracks. Bent hooks or hooks damaged from chemicals, deformation, cracks or having excessive throat opening (see paragraph 4-6) should be replaced. Visible deformation of any hook may be evidence of hoist abuse and overloading and indicates that a thorough inspection of the complete hoist should be made.
- c. Check that bottom hook swivels freely.
- d. Check for missing, bent or otherwise damaged hook latches.
- e. Check pushbutton and power cord for cuts or other damage.
- f. Check load chain for adequate lubrication, as well as for signs of excessive wear or stretch, cracked, damaged or twisted links, corrosion or foreign substance.

4-3. PERIODIC INSPECTION

The exact period for the following inspections will depend on the anticipated severity of hoist use. Determination of this period should be based on the user's experience. It is recommended that the user begin with a monthly inspection and extend the periods to quarterly, semiannually, or annually, based on his monthly inspection experience.

- a. Clean hoist of any dirt or foreign material. Inspect bottom block for accumulation of debris.
- b. Perform all frequent inspections listed above.
- c. Check for loose bolts, screws and nuts.
- d. Check housings, load block, and other parts for wear, corrosion, cracks or distortion. Check for abnormal openings between housing sections.
- e. Check motor brake for worn discs, oil contamination or excessive clearance (see paragraph 5-3).
- f. Check mechanical load brake function (see Figure 4-3).
- g. Inspect the entire length of chain for gouges, nicks, weld spatter, corrosion, distortion and wear. See CHAIN INSPECTION, paragraph 4-5.
- h. Inspect hooks and suspension parts for cracks, distortion or extreme wear.
- i. Inspect hooks for cracks using magnetic particle, dye penetrant or other crack detecting methods.
- j. Check limit switch set points and reset if necessary (see paragraph 5-2).
- k. Inspect all wiring for defective insulation, and check to be sure all electrical connections are tight. Check motor reversing contactor or relay for burned contacts.
- l. Inspect for oil leaks. Check oil level.
- m. Inspect for missing or illegible capacity or warning labels.
- n. Inspect the supporting structure for continued ability to support the hoist rated load.

INSPECTION SCHEDULE AND MAINTENANCE REPORT						
Type of Hoist				Capacity (Tons)		
Location				Original Installation Date		
Manufacturer				Manufacturer's Serial No.		
Item	Frequency of Inspection			Possible Deficiencies	OK	Action Required
	Frequent		Periodic 1-12 Months			
	Daily	Monthly				
Operating Controls	•	•	•	Any deficiency causing improper operation		
Limit Switches	•	•	• •	Any deficiency causing improper operation Pitting or deterioration		
Disc (Motor) Brake	•	•	• •	Slippage or excessive wear Glazing, contamination or excessive wear		
Load Brake/ Mechanical			•	Failure to support load with disc brake open (see paragraph 4-3 f)		
Hooks	•	•	• •	Excessive throat opening, bent or twisted more than 10 degrees, damaged hook latch, wear, chemical damage, worn hook bearing Cracks (use dye penetrant, magnetic particle or other suitable detection method)		
Suspension Lug (if used)			• •	Crack, excessive wear or other damage which may impair the strength of the lug Cracks (use dye penetrant, magnetic particle or other suitable detection method)		
Chain	•	•	•	Inadequate lubrication, excessive wear or stretch, cracked damaged or twisted links, corrosion or foreign substance		
Hook and Suspension UigConnections			•	Cracks, bending, stripped threads, loose mounting screws		
Pins, Bearings, Bushings, Shafts, Couplings, Chain Guides			•	Excessive wear, corrosion, cracks, distortion		
Nuts, Bolts, Rivets			•	Looseness, stripped and damaged threads, corrosion		
Sheaves			•	Distortion, cracks and excessive wear. Buildup of foreign substances		
Housing, Load Block			•	Distortion, cracks and excessive wear, internal buildup of foreign substances		
Wiring and Terminals			•	Fraying, defective insulation		
Contact Block, Magnetic Hoist Control Switch, Other Electrical Apparatus			•	Loose connections, burned or pitted contacts		
Supporting Structure and Trolley (if used)			•	Damage or wear which restricts ability to support imposed loads		
Nameplates, Decals, Warning Labels			•	Missing, damaged or illegible		
Transmission Lubricant			•	Low level, requires changing		
Note: Refer to Maintenance and Inspection Sections of the Hoist Maintenance Manual for further details.						
FREQUENCY OF INSPECTION: Frequent - Indicates items requiring inspections daily to monthly Daily inspections may be performed by the operator if properly designated. Periodic - Indicates items requiring inspection monthly to year y Inspections to be performed by or under the direction of a properly designated person. The exact period of inspection will I depend on frequency and type of usage. Determination of this period will be based on the user's experience. It is recommended that the user begin with a monthly inspection and extend the periods to quarterly , semi-annually or annually based on his monthly experience						

FIGURE 4-1. RECOMMENDED INSPECTION AND MAINTENANCE CHECK LIST

[illegible]

4-4. LOAD BRAKE FUNCTION CHECK


- a. Attach a light load to the hoist and lift it several inches.
- b. **DISCONNECT HOIST FROM POWER SUPPLY** and remove short end brake cover (see Figure 8-2, Index No. 1)
- c. Referring to Figure 4-3 and Figure 8-9, place screwdrivers No.1 and No.2 behind the plate and armature assembly and prepare to pry against the transmission cover.

Do not allow either screwdriver to contact brake disc (see Figure 8-9, Index No. 7).

-
- Diagram illustrating the removal of the transmission cover. The cover is shown being lifted away from the engine block. Two screwdrivers are used to remove the screws securing the cover. The diagram labels the following components:
- SCREWDRIVER NO.1
 - TRANSMISSION COVER
 - PLATE AND ARMATURE ASSEMBLY
 - SCREWDRIVER NO.2

4-5 CHAIN INSPECTION

- Check each link for gouges, nicks, weld spatter, corrosion and distortion.
- Inspect each link for wear to the diameter of the link (see Figure 4-4). The nominal link diameter is 0.250 inch for chain on models up to EC-2008 and 0.281 inch for models EC-2012 and above. If the diameter of any link of 0.250 chain is worn to less than 0.200, or the diameter of any link of 0.281 chain is less than 0.225, the entire chain must be replaced.



COFFING®
HOISTS

c. Chain Inspection

1. Check the chain for overall wear or stretch by selecting an unworn, unstretched length of chain (at the slack end, for example). Let the chain hang vertically with a light load (about 20 lbs.) on the chain to pull it taut. Use a large caliper to measure the outside length of a convenient number of links (about 12 inches). Measure the same number of links in a used section of chain and calculate the percentage increase in length of the worn chain.
2. If the length of the worn chain is more than 1.5% longer than the unused chain (0.15" per inch of chain measured), then the chain should be replaced. If the chain is worn less than 1.5%, check it at several more places along its length. If any section is worn more than 1.5%, the chain should be replaced.
- d. The chain used in this hoist is accurately calibrated to operate over the load sprocket and is very carefully heat treated for maximum wear life and strength.

⚠ WARNING

- a. Do not weld or join hoist load chain.
- b. Do not substitute another manufacturer's chain in this hoist.
- c. Damage or wear, beyond the stated limits, to any portion of the chain requires that the entire length be replaced.

4-6. HOOK THROAT OPENING

Use Table 4-1 (below) to check hook throat opening.




TABLE 4-1. MAXIMUM ALLOWABLE HOOK THROAT OPENING

Hoist Load Rating (ton)	Top Hook* (in.)	Bottom Hook* (in.)
1 ton and under	1 1/4	1 1/8
2 ton	1 1/4	1 1/4
3 ton	1 9/16	1 9/16

*Figures given are for hook with latch. Add 1/16" if measured without hook latch

SECTION V MAINTENANCE AND REPEAT

5-1. GENERAL

This section provides instruction for the most common routine maintenance and adjustments. Major repairs are not within the scope of this manual and should be referred to qualified service facilities.

Safety Notice

Always remove load and disconnect hoist from power supply before removing end covers or making repairs.

5-2. LIMIT SWITCH ADJUSTMENT

Limit switches are provided to protect the hoist against damage resulting from overtravel. For easy identification the upper (No. 2, Figure 5-1) and lower (No. 3, Figure 5-1) limit switch adjusting nuts are colored brass and zinc respectively. Each limit switch nut has ten slots for adjustment, and the increment of adjustment is such that one slot is equivalent to one link of chain travel. Care should be exercised when adjusting either limit of travel. When a geared type limit switch is furnished (long lift hoists) each adjustment is equal to 3 links of chain, or 30 links per revolution.




FIGURE 5-1. LIMIT SWITCH ADJUSTMENT

- Adjusting Upper Limit (Brass Nut).
 - Carefully raise the load block to a point where its top is 2" or more from the hoist housing
 - Disconnect Power from the hoist and remove the short end cover.
 - With a screwdriver, pry the spring guide plate (No. 1, Figure 5-1) out of the slots in the colored limit switch nut (Nos. 2 and 3).
 - Turn the slotted brass nut (No. 2) toward its limit switch until the switch clicks.
 - Release the spring guide plate and be sure it snaps back into the slots in both nuts. Do not disturb the other slotted nut if it has been previously set.
 - Replace the short end cover and reconnect power to the hoist.
 - Carefully raise the load block to its upper limit and observe to see if it stops automatically at the desired point. Do not allow the load block to run into the hoist housing. The stopping point should be at least 2" below the hoist housing.
- Adjusting Lower Limit (Zinc Nut)
 - Carefully lower the load block to a point where at least 12 links of slack chain hang down from the hoist housing.
 - Disconnect power from the hoist and remove the short end cover.

- Adjust the zinc limit switch nut in the same manner described above for the brass nut.
- Replace the short end cover and reconnect power to the hoist.
- Carefully lower the load block to its lower limit and observe if it stops automatically at the desired level. Do not run chain out of hoist or allow the slack end loop to become taut against the hoist housing. At least 12 links of slack chain should hang from the hoist.

Notice

If upper and lower limits are not operating satisfactorily, repeat adjustment.

5-3. MOTOR BRAKE ADJUSTMENT

When properly adjusted, the multiple disc motor brake should release promptly, operate without noticeable chatter, and stop the load with no more than one inch of drift. If the hoist hesitates to lift the load promptly when the pushbutton is depressed, the brake should be adjusted per the following procedure.

- Remove any load and disconnect power from hoist.
- Remove the short end cover.
- Referring to Figure 4-2, check the gap between armature (A) and frame (B). the correct gap is .015"
- Adjust the gap by turning the three lock nuts (F) and check with a feeler gauge to be sure the gap is the same on both ends of the solenoid.




FIGURE 5-2. MOTOR BRAKE ADJUSTMENT

CAUTION

Be sure the bottom of the armature does not touch the splined adapter (H). As wear occurs, the original clearance will be reduced. When this clearance is gone, THE BRAKE DISCS MUST BE REPLACED.

- Replace short end cover and reconnect power. If the brake still chatters or is hesitant to release, refer to Section VI, Troubleshooting.

5-4. TOP SUSPENSION REMOVAL AND REPLACEMENT

A number of different top suspension assemblies are available to accommodate different methods of hanging the hoist. If it should be necessary to change top suspensions, proceed as follows:

- Disconnect power from hoist and move the hoist to a safe working area. If necessary, remove trolley and/or rotate suspension lug to gain access to the socket head cap screws bolting the top suspension yoke to the frame of the hoist.
- Remove socket head screws (7/16" hex) and lift out the suspension assembly.

- c. Install new suspension assembly and tighten socket head screws to 75 ft-lbs torque.

⚠ CAUTION

Due to the off-center hood or lug hole, the suspension yoke can be installed in the hoist in two different ways. With the hoist level, the hook or lug must always be directly over the bottom hook. Refer to Figure 5-4 for the proper yoke orientations for single, double and triple chain hoists.

5-5. CHAIN REPLACEMENT (OLD CHAIN STILL IN HOIST)

Refer to Figure 5-4, Chaining and Suspension Diagrams, and proceed as follows:

- a. Run the load block up to its top limit.
- b. Disconnect power from the hoist and remove the short end cover.
- c. With a screwdriver, push the spring guide plate (No. 1 Figure 5-1) out of the slots in the limit switch nuts. Turn the brass slotted nut (No. 2) back to about the center of the threaded screw. **DO NOT DISCONNECT THE WIRES FROM THE LIMIT SWITCHES.**




FIGURE 5-3. CHAINING HOIST

- d. Remove the load hook assembly from the old chain.
- e. Make a "C" -shaped chain link by grinding through one side of the end link of either the old or new chain. See Figure 5-3.
- f. Hook the special "C" link to the end link of both chains to join them. **BE SURE** the welds of the upstanding links of the new chain are out away from the load sheave, and that proper orientation is observed for attachment of the slack end in paragraph j. below.

Note

On triple chain hoists be sure all welds are aligned like the welds on the old chain. It may be necessary to cut a link from one or both ends of the chain to accomplish this.

- g. With the end cover off, connect the hoist to power supply. Be sure the green ground wire is properly grounded.
- h. Carefully jog the "UP" button and run the joined pieces of chain into the hoist until about 12 inches of the new chain comes out the other side.
- i. **DISCONNECT POWER** from the hoist.
- j. Remove both the "C" link and the old chain from the slack end pin (No. 28, Figure 8-6). This can be accomplished by depressing the pin against the slack end spring (29) with a small screwdriver. Remove the soft split link (23) from the old chain and attach the link to the new chain. Depress the slack end pin and install the split link observing proper orientation of the slack end of the chain when secured. Avoid twists in the chain.

- k. Adjust the lower limit switch per paragraph 5-2b.

- l. Attach the bottom hook on single-chained hoists to the loose end of the chain. On double-chained hoists, feed the loose end of the chain through the load block (welds of the upstanding links will be in towards the sheave) and fasten the end of the chain to the dead end lug (No. 19 Figure 8-6).

Note

On triple chain hoists feed the loose ends of the chain through the load block (welds away from sheave) around the idler sheave in the hoist, and to the center of the load block.

- m. Adjust the upper limit switch per paragraph 5-2.a.
- n. Lubricate the new chain per paragraph 5-6.a and perform an operation test of the hoist.

5-6 LUBRICATION

Proper lubrication is necessary for long, trouble-free hoist operation. Refer to the following and to Table 5-1, Recommended Lubrication Schedule, for lubrication points, type of lubricant, and frequency of lubrication.

- a. **Load Chain** – Clean the load chain with a non-acid and non-caustic solvent and coat with SAE90 gear oil. Wipe excess oil to prevent dripping. If the hoist is used in an atmosphere containing abrasive dust, the chain should be cleaned and oiled more frequently. Never apply grease to the chain.
- b. **Gearing** – The gear case of the hoist is filled at assembly with 46 oz. of a gear oil containing special friction reducing additives.

⚠ WARNING

The use of gear oils other than that recommended in Table 5-1 can cause brake chatter or can render the load brake incapable of holding a load. A 48-oz. container of this oil is available from COFFING. (Part No. 14J1).

1. To check the oil level, remove the 1/8" pipe plug from the side of the hoist. With the hoist hanging level, transmission oil should be even with the edge of the tapped plug hole.
2. The length of time between necessary oil changes will depend on the severity of use the hoist receives. In general, the oil should be changed every 12 months of normal operation, or every 200 hours of actual hoist on-time. Very heavy use or operation in high ambient temperatures (over 105°F) will require that oil be changed more often. An indication of the need for oil replacement is load brake noise. If an erratic tapping sound is made when lowering a load, the oil should be changed.
- c. **Limit Switch Shaft** – To prevent rust, the threaded limit switch shaft should be given a light coat of grease or be sprayed with a general purpose lubricant.
- d. **Idler Sheave Bearing** (double and triple chain models only) – Use a grease gun to put about a teaspoon of grease through the grease fitting in the bottom block shaft. Avoid pumping an excessive amount of grease into the bottom block. On triple chain hoists, use a grease gun to lubricate the idler sheave in the hoist until fresh grease pumps from the end of the sheave bearing.
- e. **Hook Bearing** – Apply a few drops of SAE 30 oil around the edge of the bearing.




FIGURE 5-4. CHAINING AND SUSPENSION DIAGRAMS

TABLE 5-1. RECOMMENDED LUBRICATION SCHEDULE* MODEL EC ELECTRIC CHAIN HOIST

Figure and Index No.	Component	Type of Lubricant	Type of Service and Frequency of Lubrication		
			Heavy	Normal	Infrequent
Figure 8-6, No 7.	Load Chain	SAE 90 Gear Oil	Daily	Weekly	Monthly
Figure 8-5	Gearing	Coffing No. H-7813 transmission oil (Kit No. 14J1 contains quantity of oil sufficient for one oil change)	At periodic inspection (See Figure 4-1, paragraph 5-6-2)		
Figure 8-8A, No. 8; Figure 8-8B, No. 7	Limit Switch Shaft	“WD-40” or general purpose spray lubricant	Monthly	Yearly	Yearly
Figure 8-10, No.____ & No.____	Load Hook Bearing	SAE 30 Gear or Motor Oil	Weekly	Monthly	Yearly
Figure 8-1, Nos. 1, 2, 3, 4, 5, 6 & 7	Top Hook or Suspension Lug Bearing Surfaces	SAE 30 Gear or Motor Oil	Monthly	Yearly	Yearly
Figure 8-10C, No 11 Figure 8-10D, No.11	Idler Sheave Bearing (Bushing)	NLGI #2 multi-purpose lithium base grease (Coffing No. H-7610)	At periodic inspection (See Figure 4-1)		

Note: All bearings except hook and idler sheave bearings are pre-lubricated and sealed.

* This lubrication schedule is based on a hoist operating in normal environmental conditions. Hoists operating in adverse atmospheres containing excessive heat, corrosive fumes or vapors, abrasive dust, etc. should be lubricated more frequently.

SECTION VI TROUBLESHOOTING

6-1. GENERAL

Use the following table as an aid to troubleshoot your hoist. If you do not have an experienced machinist-electrician to do your repair work, we recommend that you send your hoist to an approved service center for repairs.

	Probable Cause	Remedy
Hook Fails to Stop at End of Travel.	1. Limit switches not operating.	1. Check adjustment. See paragraph 5-2. Check connections against wiring diagram. Tighten loose connections or replace.
	2. Limit switch nuts not moving on shaft.	2. Check for stripped threads or bent nut guide.
	3. Magnetic reversing switch malfunction.	3. Remove electrical cover and check reversing switch.
Hoist Does Not Respond to Pushbutton.	1. Power failure in supply lines.	1. Check circuit breakers, switches and connections in power supply lines.
	2. Wrong voltage or frequency.	2. Check voltage and frequency of power supply against the rating on the nameplate of the hoist.
	3. Improper connections in hoist or pushbutton station.	3. Check all connections at line connectors and on terminal block. Check terminal block on dual voltage hoists for proper voltage connections.
	4. Motor brake does not release.	4. Check connections to the solenoid coil. Check for open or short circuit. Check for proper adjustment. See paragraph 5-3.
	5. Faulty magnetic hoist control switch.	5. Check coils for open or short circuit. Check all connections in control circuit. Check for burned contacts. Replace as needed.
Hook Does Not Stop Promptly.	1. Hoist overloaded.	1. Reduce load to within rated capacity of hoist.
	2. Brake not holding.	2. Check motor brake adjustment (see paragraph 5-3) and load brake (Figure 4-3).
Hook Moves in Wrong Direction.	1. Three-phase reversal.	1. Reverse any two wires (except the green ground wire) at the power source (see paragraph 2-3).
	2. Improper connections.	2. Check all connections against Wiring Diagram.
Hoist Hesitates to lift When Energized.	1. Hoist overloaded.	1. Reduce load to within rated capacity of hoist.
	2. Motor brake requires adjustment.	2. Check motor brake adjustment (see paragraph 5-3)
	3. Worn overload limiting clutch.	3. Replace clutch.
	4. Low voltage.	4. Check voltage at hoist power cord with hoist starting. Voltage should be no less than 90% of voltage specified on hoist.
	5. Faulty SINPAC starting switch or start capacitor (single phase hoists only).	5. Replace faulty component
Hook Raises But Will Not Lower. (Motor not running)	1. "Down" circuit open.	1. Check circuit for loose connections. Check "Down" limit switch for malfunction.
	2. Broken conductor in pushbutton cable.	2. Check each conductor in the cable. If one is broken, replace entire cable.
	3. Faulty magnetic hoist control switch.	3. Check coils for open or short circuit. Check all connections in control circuit. Check for burned contacts. Replace as needed.
Hook Raises But Will Not Lower When Motor Is Operating.	Consult Factory or Authorized Duff-Norton Warranty Repair Station.	
Hook Lowers But Will Not Raise.	1. Hoist overloaded.	1. Reduce load to within rated capacity.
	2. Low voltage.	2. Determine cause of low voltage and bring up to at least 10% of the voltage specified on hoist. Line voltage should be measured while holding or lifting load.
	3. "UP" circuit open.	3. Check circuit for loose connections. Check "UP" limit switch for malfunction.
	4. Broken conductor in pushbutton cable.	4. Check each conductor in the cable. If one is broken, replace entire cable.
	5. Faulty magnetic hoist control switch.	5. Check coils for open or short circuit. Check all connections in control circuit. Check for burned Contacts. Replace as needed.
	6. Faulty SINPAC Starting Switch or capacitor (single-phase hoists only).	6. Replace faulty component.
	7. Worn overload limiting clutch.	7. Replace clutch.

SECTION VI TROUBLESHOOTING

	Probable Cause	Remedy
Lack of Proper Lifting Speed.	1. Hoist overloaded.	1. Reduce load to within rated capacity of hoist.
	2. Motor brake is dragging.	2. Check for proper brake adjustment or other defects. See paragraph 5-3.
	3. Low voltage.	3. Bring up voltage to plus or minus 10% of voltage specified on hoist. Line voltage should be measured while hoist is lifting load.
	4. Overload limiting clutch intermittently slipping.	4. Replace clutch,
Load Brake "Noise." (Erratic tapping sounds or squeals)	1. Need transmission oil change, or improper lubricant has been used.	1. Change transmission oil. See Table 5-1. Note: Hoist Warranty is void if unapproved oil is used.
	2. Load brake malfunctioning.	2. Check load brake operation. See Figure 4-3.
Motor Brake Noise or Chatter. (While starting hoist)	1. Brake needs adjustment.	1. Adjust as per paragraph 5-3.
	2. Low voltage.	2. Check voltage at hoist power cord with hoist starting. Voltage should be no less than 90% of the voltage specified. 115 volt hoists are particularly subject to voltage drop problems due to their high current draw. Conversion to 230 volt operation is suggested in extreme cases.
Motor Brake "Buzz." (Anytime hoist is running)	1. Brake needs adjustment.	1. Adjust as per paragraph 5-3.
	2. Broken shading coil on brake frame.	2. Replace shading coil or complete brake frame assembly.

* A more detailed explanation of electronics troubleshooting can be found with the CM interface cable kit. This procedure requires use of extracted fault codes from the hoist memory, plus multimeter readings.

SECTION VII WIRING

SAFETY NOTES

Disconnect power from hoist before removing end covers.

7-1. WIRING DIAGRAMS

The wiring diagrams for standard hoist models are reproduced on the following pages. In addition, every hoist should have a wiring diagram located inside the long end cover.

7-2. VOLTAGE CONVERSION

Standard single phase units are convertible from 115 to 230 volts, and standard single speed three phase units are convertible from 460 to 230 volts. Conversion to the alternate voltage can be accomplished with the following procedure.

- a. Be sure power is disconnected from hoist. Remove long end cover.
- b. SINGLE PHASE HOISTS (with SINPAC® switch): Transfer leads per the appropriate terminal block schematic.
- c. THREE PHASE HOISTS: Transfer leads per the appropriate terminal block schematic.

CAUTION

Do not move any wires or make any changes to the wiring except at the terminal block.

After converting voltage, check for proper phasing of three phase units and check for proper limit switch operation.

FIGURE 7-1. 115V, 230V - 1 PHASE, 1-SPEED HOIST 981EE2100-000





FIGURE 7-2. 230V, 460V - 3 PHASE, 1-SPEED HOIST 983EE2100-000



SUPPLY VOLTAGE: 460 VAC

WIRING DIAGRAM
230V OR 460V - 3 PHASE
SINGLE-SPEED HOIST
DWG# 983EE2100-000

FIGURE 7-3. 208V, 380V 575V - 3 PHASE, 1-SPEED HOIST 98* EE2100-000





FIGURE 7-4. 208V, 230V, 460V, 575V - 3 PHASE, 2-SPEED HOIST 98* EE2200-000



SECTION VIII

REPAIR PARTS LIST

WARNING

Using “Commercial” or other manufacturer’s parts to repair the COFFING Hoists may cause load loss.

TO AVOID INJURY

Use only COFFING supplied replacement parts. Parts may look alike but COFFING parts are made of specific materials or processed to achieve specific properties

ORDERING INSTRUCTIONS

The following information must accompany all correspondence orders for replacement parts:

1. Hoist Model Number from identification plate.
2. Serial number of the hoist from identification plate.
3. Voltage, phase, hertz from the identification plate.
4. Length of lift.
5. Part number of part from parts list.
6. Number of parts required.
7. Part name from parts list.



NOTE: When ordering replacement parts, it is recommended that consideration be given to the need for also ordering such items as gaskets, fasteners, insulators, etc. These items may be damaged or lost during disassembly, or just unfit for future use because of deterioration from age or service.

8-1. GENERAL

The following exploded drawings provide a complete list of parts used in the standard EC hoist models (shown in Table 1-1 . page 3). Since several different models of hoists are covered by this manual, differences may be noted between the appearance of your hoist part and the reference illustration. If this is the case, the parts list will show several different part numbers with sufficient information to allow the selection of the correct part number.

8-2. HOW TO USE THE PARTS LIST

- a. The parts list consists of four columns as follows:
 1. Index Number
 2. Usage Code — This column may contain a code relating to the model numbers of, or other data relating to the hoist in which the part is used. Usage codes are as follows:
 - A. Single Phase Hoists (Single Speed)
 - B. Three Phase Hoists (Single Speed)
 - C. Three Phase Hoists (Two Speed)
 - D. Hoists with 1/4 in. Load Chain (Models EC-0516, EC-0532, EC-0564, EC-1009, EC-1016, EC-1032, EC-2004 and EC-2008))
 - E. Hoists with 9/32 in. Load Chain (Models EC-2012, EC-2016, EC-4006, EC-4008 and EC-6005)
 - F. Single Chain Hoists (Models EC-0516, EC-0532, EC-0564, EC-1009, EC-1016, EC-1032)
 - G. Double Chain Hoists (Models EC-2004, EC-2008, EC-4006, EC-4008)
 - H. Single Chain Hoists (Models EC-2012, EC-2016)
 - J. Triple Chain Hoists (Model EC-6005)
 3. Part Number
 4. In addition to basic part name. This column contains descriptions which are essential for choosing the correct part number when more than one is listed.

- b. How to determine proper part number:

1. Locate the index number in the corresponding figure of the parts list.
2. If only one part number is listed for the index number, that part number should be ordered.
3. If more than one usage code and part number is listed for that index number. Choose the correct usage code by comparing the model number or electrical characteristics of your hoist with the usage codes above.

EXAMPLE A

Index No.	Usage Code	Part No.	Part Name
6	E	35J1	Transmission Housing
	D	35J2	Transmission Housing

4. If more than one part number is listed with the same usage code, the information under “part name” will determine the correct part number. This is also the case if no usage code is listed and more than one part number is listed for the index number.


EXAMPLE B

Index No.	Usage Code	Part No.	Part Name
4	B	821J432	Transformer (Pri 230/460V, Sec. 24V)
	B	821J431	Transformer (Pri 230/460V, Sec.115V)

8-3. HOW TO FIND YOUR HOIST MODEL NUMBER AND SERIAL NUMBER

When ordering parts or requesting information concerning your EC hoist, always include the hoist model number and serial number. A product label with this information is located near the power cord entry hole on the side of the hoist as shown below. There is also a serial number label on the hoist near the electric brake and limit switch under the brake cover.

See illustration below.




When ordering motor parts, please provide complete motor nameplate data, including motor “ref.” number or model number.


NOTE

Repair parts are available only from Coffing distributors or authorized repair facilities. It is recommended that repair part orders be directed to the authorized repair facility nearest you.


PARTS LIST FOR SUSPENSION ASSEMBLIES




2 TON & UNDER MODELS




3 TON MODEL ONLY




2 TON & UNDER MODELS




3 TON MODEL ONLY



2 TON & UNDER MODELS



3 TON MODEL ONLY



2 TON & UNDER MODELS

FIGURE 8-1 - SUSPENSION ASSEMBLIES

Index No.	Usage	Part No.	Part Name
1	F,G,H	14J25	Hook Assembly Kit, Swivel
		14J26	Hook Assembly Kit, Rigid
2	J	3JG23	Hook Assembly, Rigid(3-Ton Only)
3	F,G,H	14J3	Trolley Lug Assembly Kit Plain, Geared & Parallel Mounted Motorized Trolley
4	J	50JG53	Trolley Lug Assembly (Plain or Geared Trolley Only) 3-Ton Only
5	F,G,H	14J4	Trolley Lug Assembly Kit, Cross Mounted Motorized Trolley
6	J	50JG54	Trolley Lug Assembly, (Motorized Trolley Only) 3-Ton Only
7	F,G,H	50JG22	Multi-Purpose Lug Assembly

FIGURE 8-2 BASIC HOIST




FIGURE 8-2 BASIC HOIST

Index No.	Usage	Part No.	Part Name
1		36J1	Brake Cover
2		36J2	Electrical Cover
3		560J4	Gasket, brake & Electrical Covers
4		33J1	Sheave Housing (Models EC-2012, EC2016, EC4006 & EC4008)
		33J2	Sheave Housing (Models EC0564 & EC1032)
		33J2-1	Sheave Housing (EC0516, EC0532, EC1009, EC1016, EC2004 & EC2008)
	J	33J19	Sheave Housing (Model EC6005)
5		34JG1	Transmission Cover (includes 2 oil seals)
6	E	35JG1	Transmission Housing
	D	35JG2	Transmission Housing
7	A	951JL1	Power Cable (1/4 & 1/2 HP) #14 Gauge, 3 Conductors
	A	952JL1	Power Cable (1 HP) #12 Gauge, 3 Conductors
	B	953JL1	Power Cable #14 Gauge, 4 Conductors
8	A&B	940JE1	Wiring Harness 1-Speed
	C	940JE1-36	Wiring Harness 2-Speed
9		H2923P	Screw(slotted hex head)
10		675J1B	Decal, Capacity 1/4 Ton
		675J2B	Decal, Capacity 1/2 Ton
		675J3B	Decal, Capacity 1 Ton
		675J4B	Decal, Capacity 2 Ton
		675J11	Decal, Capacity 3 Ton
11		H4002P	Flat Washer
12		677J2	Decal, Coffing
13		H2981P	Screw
14		560J5	Gasket, Trans.
15		676J2B	Decal, Coffing
16	A	679J1	Decal, Power Requirements(115/230V)
	B	679J2	Decal, Power Requirements (230/460V)
	A,B,C	679J3	Decal, Power Requirements (230V)
	B&C	679J4	Decal, Power Requirements (460V)
	B&C	679J5	Decal, Power Requirements (575V)
	B&C	679J36	Decal, Power Requirements (208V)
20			Suspension Assembly Kit (Ref. #1, 2, 3, 4, 5, 6 & 7, Figure 8-1)
21		703J1	Screw(Included in all Suspension Assembly Kits)
22		H4086P	Lock Washer (Included in all Suspension Assembly Kits)
23			Pushbutton Cable (Ref. Figure 8-7A & 8-7B)
24A		H6293	Reducer Bushing
24B		SK1912-21W	Pressure Relief Plug
25		H2970	Screw
26		S25-13	Level Plug
27	F,G,H	4X1305	Latch Kit
	J	4X1307	Latch Kit (3Ton Only)
28		JF679-1	Tag (230V-1 Phase)
		JF679-2	Tag (230V-3 Phase)
		JF679-3	Tag (460V-3 Phase)
		JF679-4	Tag (115V-1Phase)




FIGURE 8-3A MOTOR PARTS (ONE SPEED)

† Refer to the motor nameplate for part number, voltage, full load amperage, horsepower, and other motor information.

Ref No.	Part No.	Description	Qty
1	Hoist Motor (1-Speed)		
	861J241B	1/4 hp, 115/230V-1Ph	1
	861J242B	1/2 hp, 115/230V-1Ph	1
	861J144B	1 hp, 115/230V-1Ph	1
	863J241B	1/4 hp, 230/460V-3Ph-60Hz	1
	863J242B	1/2 hp, 230/460V-3Ph-60Hz	1
	863J144B	1 hp, 230/460V-3Ph-60Hz	1
	863J244B	1/4 hp, 575V-3Ph-60Hz	1
	863J245B	1/2 hp, 575V-3Ph-60Hz	1
	863J148B	1 hp, 575V-3Ph-60Hz	1
	863J247B	1/4 hp, 208V-3Ph-60Hz	1
	863J248B	1/2 hp, 208V-3Ph-60Hz	1
	863J149B	1 hp, 208V-3Ph-60Hz	1
	863J241B	.21 hp, 380V-3Ph-50Hz	1
	863J242B	.42 hp, 380V-3Ph-50Hz	1
	863J144B	.83 hp, 380V-3Ph-50Hz	1

Ref No.	Part No.	Description	Qty
2	*	Adaptor Plate (1HP Only)	
3	*	Stator Assembly	
4	*	Rotor Assembly	
5	*	End Shield	
6	500K3	Bearing	2
7	*	Thru Bolt	
8	*	#10 Spring Lockwasher	

* Not available as an individual part.




FIGURE 8-3B MOTOR PARTS (TWO SPEED)

† Refer to the motor nameplate for part number, voltage, full load amperage, horsepower, and other motor information.

Ref No.	Part No.	Description	Qty
1	Hoist Motor (2-Speed)		
	873J241B	1/4 hp, 230V-3Ph-60Hz	1
	873J242B	1/2 hp, 230V-3Ph-60Hz	1
	873J144B	1 hp, 230V-3Ph-60Hz	1
	873J244B	1/4 hp, 460V-3Ph-60Hz	1
	873J245B	1/2 hp, 460V-3Ph-60Hz	1
	873J148B	1 hp, 460V-3Ph-60Hz	1
	873J247B	1/4 hp, 575V-3Ph-60Hz	1
	873J248B	1/2 hp, 575V-3Ph-60Hz	1
	873J152B	1 hp, 575V-3Ph-60Hz	1
	873J251B	1/4 hp, 208V-3Ph-60Hz	1
	873J249B	1/2 hp, 208V-3Ph-60Hz	1
	873J145B	1 hp, 208V-3Ph-60Hz	1

Ref No.	Part No.	Description	Qty
2	*	Adaptor Plate (1HP Only)	
3	*	Stator Assembly	
4	*	Rotor Assembly	
5	*	End Shield	
6	500K3	Bearing	2
7	*	Thru Bolt	
8	*	#10 Spring Lockwasher	

* Not available as an individual part.




FIGURE 8-4A PARTS LIST FOR ELECTRICAL PARTS FOR 115/230V - 1-PHASE MODELS

Ref No.	Part No.	Description	Qty
1	839J3	Starting Switch	1
2	Capacitor		
	JL810-3	1/4 & 1/2 hp	1
	JL810-4	1 hp	1
3	257JG200	Panel Plate	1
4	Reversing Contactor*		
	1/4 & 1/2 hp:		
	28860	24V Coil	1
	24799	115V Coil	1
	1 hp, 1-Phase:		
	24791	24V Coil	1
	28905	115V Coil	1
5	Transformer*		
	821J412	Sec.: 24V	1
	821J411	Sec.: 115V	1
6	909J10	Terminal Block	2

Ref No.	Part No.	Description	Qty
7	909J14	Terminal Block	4
8	909J15	End Plate	1
9	909J13	End Clamp	2
10	H2751	8-32UNC X 5/16" Screw	2
11	H4158	#8 External-tooth Lockwasher	2
12	H7956	Grommet	2
13	H9006	Cable Tie	4
▲	15 ft Power Cord Assembly		
	951JL1	115/230V, 1/4 & 1/2 hp	1
	952JL1	115/230V, 1 hp	1

* Coil voltage of the contactor and the secondary voltage of the transformer are the same. This is referred to as the control voltage. Standard units are supplied with 24V Control.

▲ Not Shown




FIGURE 8-4B PARTS LIST FOR ELECTRICAL PARTS FOR 3-PHASE MODELS

Ref No.	Part No.	Description	Qty
1	257JG200	Panel Plate	1
2	Reversing Contactor*		
	1/4 & 1/2 hp:		
	28860	24V Coil	1
	24799	115V Coil	1
	1 hp :		
	25943	24V Coil	1
	24729	115V Coil	1
3	Speed Control Relay* (2-Speed Only)		
	28878	1/4 & 1/2 hp, 24V Coil	1
	28870	1/4 & 1/2 hp, 115V Coil	1
	820J34	1 hp, 24V Coil	1
	820J35	1 hp, 115V Coil	1
4	Transformer*		
	821J432	Pri.: 230/460V, Sec.: 24V	1
	821J431	Pri.: 230/460V, Sec.: 115V	1
	821J452	Pri.: 575V, Sec.: 24V	1

Ref No.	Part No.	Description	Qty
4	821J451	Pri.: 575V, Sec.: 115V	1
	821J472	Pri.: 208V, Sec.: 24V	1
	821J471	Pri.: 208V, Sec.: 115V	1
	821J482	Pri.: 380V, Sec.: 24V	1
	821J481	Pri.: 380V, Sec.: 115V	1
5	Terminal Block		
	909J10	230/460V, 1-Speed Models	8
6	End Plate		
	909J12	230/460V, 1-Speed Models	1
7	909J13	End Clamp	2
8	H2751	8-32UNC X 5/16" Screw	2
9	H4158	#8 External-tooth Lockwasher	2
10	H7956	Grommet	2
▲	953JL1	15 ft Power Cord Assembly	1

* Coil voltage of the contactor and the secondary voltage of the transformer are the same. This is referred to as the control voltage. Standard units are supplied with 24V Control.

▲ Not Shown




FIGURE 8-5 TRANSMISSION

Ref No.	Usage Code	Part No.	Description
1		34JG1	Motor, Complete Transmission Cover
2		561 K2	Seal
3		MA-562	Seal
4		404J1	Output Pinion
5		407JG25	Output Gear Assembly
6		580J8	Brake Disc (all models except EC-0564)
7		5J6	Pressure Plate
6		130J3	Nut
9		7JG15-1	Ratchet (all models except 0564)
9		7J14	Spacer (EC0564 only)
10		H-2255	Screw
11		H-4133	Lock Washer
12		H-5382	Dowel Pin
13		H-2978-P	Screw
14		H-5503	Retaining Ring
15		H-6258	Fill Plug, Vented
16		S-25-13	Level Plug
17		560J5	Gasket (Ref. #14, Figure 8-2)
18		H-6268	Drain Plug
19	E	35JG1	Transmission Housing
	D	35JG2	Transmission Housing
20		500K7	Bearing
21		400J1	Input Pinion (Models EC-2012, EC-2016, EC-4006, EC-4008 & EC-6005)
		400J2	Input Pinion (Models EC-0516, EC-1016 & EC-2008)
		400J3	Input Pinion (Models EC0532 & EC-1032)
		400J4	Input Pinion (Model EC-0564)
		400J9	Input Pinion (Models EC-1009 & EC-2004)
22		401J1	Input Gear (Models EC-2012 & EC-4006)
		401J2	Input Gear (Models EC-0516, EC- 1016 & EC-2008)

Ref No.	Usage Code	Part No.	Description
22		401J3	Input Gear (Models EC-0532 & EC-1032)
		401J5	Input Gear (Models EC-2016, EC-4008 & EC-6005)
		401J9	Input Gear (Models EC-1009 & EC-2004)
23		591JG1	Slip Clutch Assembly (Models EC-0516)
		591JG2	Slip Clutch Assembly (Model EC-0532)
		591JG3	Slip Clutch Assembly (Model EC-0564)
		591JG4	Slip Clutch Assembly (Models EC-1016 & EC-2008)
		591JG5	Slip Clutch Assembly (Model EC-1032)
		591JG6	Slip Clutch Assembly (Models EC-2012 & EC-4006)
		591JG7	Slip Clutch Assembly (Models EC-2016, EC-4008 & EC-6005)
24		591JG20	Slip Clutch Assembly (Model EC-1009 & EC-2004)
		402J1	Intermediate Pinion (Models EC-2012, EC-4006, EC-1009 & EC-2004)
		402J2	Intermediate Pinion (Models EC-0516, EC- 1016, EC-2008, EC-2016,EC-4008 & EC-6005)
25		402J3	Intermediate Pinion (Models EC-0532 & EC-1032)
		H-5549	Retaining Ring (Models EC-0516, EC-1016,EC-2008, EC-2016,EC-4008 & EC-6005)
		H-5553	Retaining Ring (Models EC-2012, EC-4006, EC- 1009 & EC-2004)
26		H-5530	Retaining Ring (Models EC-0532 & EC-1032)
		14J1	Transmission Oil Replacement Kit, (Includes Oil Required for One Oil Change)
28	D	132JG22	Sheave Shaft Assembly
28	E	132JG21	Sheave Shaft Assembly
29		500K29	Bearing
30		H-5539	Retaining Ring
31		H-5493	Dowel Pin, Ratchet Ring
32		14J2	Seal Kit (Includes Three 561K2 Seals, One MA-562 Seal and One 560J5 Gasket)
33		25JG4-1	Pawl Assembly




FIGURE 8-6 CHAINING PARTS

Ref No.	Usage Code	Part No.	Description
6	D	500K28	Bearing
6	E	500K5	Bearing
7	D	JL19B	Load Chain (1/4 in)
7	E	JL19-1	Load Chain (9/32 in)
18	G	4J3	Dead End Lug
19	G	18J1	Dead End Pin
20	E	272J1	Chain Guide Plate (9/32 in Chain)
20	D	272J2	Chain Guide Plate (1/4 in Chain)
21		127J1	Spacer, Chain Guide Plate
22	G	H-5025-P	Cotter Pin
23		H-7596	Split Chain Link
24	F,G,H	H-2978-P	Screw
24	J	H-2232	Screw
25		H-2976-P	Screw
26			Transmission Housing (Ref #6, Figure 8-2)
27			Sheave Housing (Ref #4, Figure 8-2)
28		H-5490-P	Pin, Slack end
29		23J2	Spring, Slack end
30		500K29	Bearing, (Ref #29, Figure 8-5)
31		H-5539	Retaining Ring, (Ref #30, Figure 8-5)

*Split Link is not required once chain container is installed

Ref No.	Usage Code	Part No.	Description
32			Sheave Shaft (Ref. #28, Figure 8-5)
34	D	16J2	Sheave (1/4 in Chain)
34	E	16J1	Sheave (9/32 in Chain)
35	D	JF-250-3	Chain Guide (1/4 in Chain)
35	E	JF-254-3	Chain Guide (9/32 in Chain)
36	F,G,H	107J1	Drive Coupling
36	J	107JG7-4	Drive Coupling
37	F,G,H	107J1	Retainer Block
38		H-5382	Dowel Pin
43	J	122J16	Idler Shaft
44	J	170J4	Retainer Block
45	J	255K31	Washer
46	J	530J35	Sleeve Bearing
47	J	28J12	Idler Sheave
48	J	H-5219	Grooved Pin
49	J	H-7818	Grease Fitting
50	D,E	285J21	Round Wire Retaining Ring
51	D,E	201J3	Sleeve
52 (A)	E	75J6	9/32" End Stop Frame
52 (B)	D	75J7	1/4" End Stop Frame




FIGURE 8-7A PUSH BUTTON (SINGLE SPEED HOISTS)

Ref No.	Part No.	Description
1	Push Button Station & Control Cable Assembly (Consists of Ref. No 2-10)	
	PB2100 6	Push Button Cable Assembly 6 ft. Cable Length (Consists of Ref No 2-10)
	PB2100 11	Push Button Cable Assembly 11 ft. Cable Length (Consists of Ref No 2-10)
	PB2100 16	Push Button Cable Assembly 16 ft. Cable Length (Consists of Ref No 2-10)
	PBS2100-*	Special Drop (* Equal to the Cable Length)
2	36900R	Push Button Station (Consists Ref. No. 3-7, & 9)
3	36998R	Enclosure
4	36986	Gasket
5	36987	Contact Assembly (Consists of Ref. No. 5 & No.6)
6	36988	Button Assembly
7	36989	Grommet
8	PBC2100 6	Control Cable Assembly 6 ft. Cable Length
	PBC2100 11	Control Cable Assembly 11 ft. Cable Length
	PBC2100 16	Control Cable Assembly 16 ft. Cable Length
	PBCS2100 *	Special Drop (* Equal to the Cable Length)
9	36939	Hardware Kit
10	687K3W	Warning Tag




FIGURE 8-7B PUSH BUTTON (TWO SPEED HOISTS)

Ref No.	Part No.	Description
1	Push Button Station & Control Cable Assembly (Consists of Ref. No 2-9)	
	PB2200 6	Push Button Cable Assembly 6 ft. Cable Length (Consists of Ref No 2-9)
	PB2200 11	Push Button Cable Assembly 11 ft. Cable Length (Consists of Ref No 2-9)
	PB2200 16	Push Button Cable Assembly 16 ft. Cable Length (Consists of Ref No 2-9)
	PBS2200-*	Special Drop (* Equal to the Cable Length)
2	36800R	Push Button Station (Consists Ref. No. 3-6)
3	36998R	Enclosure
4	36986	Gasket
5	70964	Contact Assembly (Consists of Ref. No. 5 & No.6)
6	36988	Button Assembly
7	36866	Grommet
8	PBC2200 6	Control Cable Assembly 6 ft. Cable Length
	PBC2200 11	Control Cable Assembly 11 ft. Cable Length
	PBC2200 16	Control Cable Assembly 16 ft. Cable Length
	PBCS2200 *	Special Drop (* Equal to the Cable Length)
9	36939	Hardware Kit
10	687K3W	Warning Tag




FIGURE 8-8A PARTS LIST FOR LIMIT SWITCH ASSEMBLY

Ref No.	Part No.	Description	Qty
1	918JG4	Limit Switch Assembly (Includes items 3-11)	1
2	918JG3	Limit Switch Bracket Assembly (Includes items 3-6)	1
3	815J1	Switch	2
4	H1402P	6-32UNC X 1" Screw	4
5	H3944	6-32UNC Elastic Locknut	4
6	JF900-3	Limit Switch Bracket (Includes Item 7)	1
7	JF531-4	Bushing	1
8	JF117-3S	Limit Switch Shaft	1
9	SK6000-63Z	Limit Switch Nut (silver)	1
10	SK6000-63W	Limit Switch Nut (gold)	1
11	H5520	Retaining Ring	1
12	JF343-3	Spring	1
13	H2970	10-24UNC X 1/2" Screw	2





FIGURE 8-8B PARTS LIST FOR LONG LIFT LIMIT SWITCH ASSEMBLY

Ref No.	Part No.	Description	Qty
1	944JG6	Long Lift Limit Switch Assembly (all items except 19)	
2	129J1	Mounting Plate	1
3	255K 16	Thrust Washer	1
4	PB-287	Spring	1
5	SK6000-63Z	Limit Switch Nut (Zinc/Silver)	1
6	SK6000-63W	Limit Switch Nut (Brass/Gold)	1
7	117JG2	Shaft and Gear Assembly	1
8	JF531 4	Bushing	1
9	258J8	End Plate	1
10	H4158	Lock Washer	3
11	H2741P	Screw	3
12	815J1	Switch	2
13	H3944	Locknut	4
14	427J1	Drive Pinion	1
15	258JG7	Frame and Guide Assembly	1
16	H1402P	Screw	4
17	854823	Screw	2
18	H5520	Retaining Ring	1
19	H2981P	Mounting Screw	2
20	H1210	Flat Head Screw	1
21	110J14	Post	1

FIGURE 8-9 MOTOR BRAKE PARTS



Ref No.	Usage Code	Part No.	Description
1	A	854JG6	Disc Brake Assembly (1/4 & 1/2 HP, 115/230 V Hoists)
	A	854JG1	Disc Brake Assembly (3/4 & 1 HP, 115/230 V Hoists)
	B	854JG7	Disc Brake Assembly (1/4 & 1/2 HP, 230/460 V Hoists)
	B	854JG2	Disc Brake Assembly (3/4 & 1 HP, 230/460 V Hoists)
	C	854JG7	Disc Brake Assembly (1/4 & 1/2 HP, 230V Hoists)
	C	854JG2	Disc Brake Assembly (3/4 & 1 HP, 230 V Hoists)
	C	854JG8	Disc Brake Assembly (1/4 & 1/2 HP, 460 V Hoists)
	C	854JG3	Disc Brake Assembly (3/4 & 1 HP, 460 V Hoists)
	B,C	854JG9	Disc Brake Assembly (1/4 & 1/2 HP, 575 V Hoists)
	B,C	854JG4	Disc Brake Assembly (3/4 & 1 HP, 575 V Hoists)
	B,C	854JG10	Disc Brake Assembly (1/4 & 1/2 HP, 208 V Hoists)
	B,C	854JG5	Disc Brake Assembly (3/4 & 1 HP, 208 V Hoists)
2		857JG1	Plate and Frame Assembly
3		858JG1	Plate and Armature Assembly
4		859JG1	Plate and Stud Assembly
5		291J1	Brake Plate

Ref No.	Usage Code	Part No.	Description
6		JF-344	Spring
7		581J1A	Brake Disc
8		JF-710	Retainer
9		H-3978	Locking Nut
10	A	JF-853-1	Coil (115 V, 60 Hz, For Brake 854JG6, 854JG1)
	B,C	JF-853-2	Coil (230 V, 60 Hz, For Brake 854JG7, 854JG2)
	C	JF-853-3	Coil (460 V, 60 Hz, For Brake 854JG8, 854JG3)
	B,C	JF-853-4	Coil (575 V, 60 Hz, For Brake 854JG9, 854JG4)
	B,C	JF-853-5	Coil (208 V, 60 Hz, For Brake 854JG 10, 854JG5)
11		141J2	Spacer (1/4 & 1/2 HP models only)
12		H-2976-P	Screw
13		142J1	Brake Adapter
14		H-5501	Retaining Ring
15		34JG1	Transmission Cover (Ref #5, Figure 8-2)
16		860J1	Shading Coil Element (Must be attached to frame with H-7812 Adhesive)
17		H-7812	Adhesive (1-oz. Tube)
18		676J1	Decal, Load Equalizer
19		H-4134	Lock Washer




FIGURE 8-10A. (1/4 TON & 1/2 TON MODELS)




FIGURE 8-10B. (1TON MODELS)




FIGURE 8-10C. (DOUBLE CHAIN MODELS)




FIGURE 8-10D. (TRIPLE-CHAIN MODELS) 3 TON ONLY

Ref No.	Usage Code	Part No.	Description
1	F,H	3JG20S	Hook & Latch Assembly
2	F,H	4X1304	Latch Kit
3	F	JF20-2	Load Block Frame
4	F	JF20-3	Load Block Frame
5	F	JF700	Screw
6	F	913JG4AS	Bottom Block Assembly
8	G	914JG2	Bottom Block Assembly (Models EC2004 & EC2008)
	G	914JG4	Bottom Block Assembly (Models EC4006 & EC4008)
9	G	3KG1	Hook & Latch Assembly (Models EC4006 & EC4008)
	G	3KG6	Hook & Latch Assembly (Models EC2004 & EC2008)
11	G	16JG7	Sheave & Bearing Assembly (Models EC2004 & EC2008)
	G,J	16JG6	Sheave & Bearing Assembly (Models EC4006, EC4008 & EC6005)
12	G	30J2	Frame (Models EC2004 & EC2008)
	G	30J4	Frame (Models EC4006 & EC4008)

Ref No.	Usage Code	Part No.	Description
13	G,J	122JG3	Shaft Assembly
14	G,J	255K2	Washer
15	G,J	H2403P	Screw
16	G,J	H4085P	Lock Washer
17	G	H3473P	Hex Nut
	J	H3964P	Hex Nut
18	J	30J20	Frame
19	J	3JG14S	Hook & Latch Assembly
20	J	4X1307	Latch Kit
21	J	18J8	Dead End Pin
22	J	914JG23	Bottom Block Assembly
23	H	30J14	Frame
25	H	S49-77	Screw
26	H	H4134	Lock Washer
27	H	913JG3AS	Bottom Block Assembly




FIGURE 8-11. CHAIN CONTAINER ASSEMBLIES (1/4 TON & 1/2 TON MODELS)

Index No.	Part No.	Part Name
1	927JG17	Chain Container Kit (20 Feet chain max.)
1	927JG18	Chain Container Kit (25 Feet chain max.)
1	927JG19	Chain Container Kit (35 Feet chain max.)
1	927JG20	Chain Container Kit (50 Feet chain max.)
2	927J17	Container (20 Feet chain max.)
2	927J18	Container (25 Feet chain max.)
2	927J19	Container (35 Feet chain max.)
2	927J20	Container (50 Feet chain max.)
3	267J3	Mounting Arm
4	53J4	Chain Section
5	H7929	Split Link*
6	H2349	Screw

*Split Link is not required once chain container is installed

FIGURE 8-12. CTA PLAIN TROLLEY ASSEMBLY





FIGURE 8-13. CTA GEARED TROLLEY ASSEMBLY



Ref No.	Part No.	Description	Qty
1	H5501	Retaining Ring	1
2	420K1	Pinion	1
3	525K2	Thrust Bearing (.063" Thick)	1
4	100K14	Gear Shaft (Parallel-Mounted)	1
4	100K14-3	Gear Shaft (Cross-Mounted)	1
5	530K6	Sleeve Bushing	2
6	51KG1	Sleeve and Adapter Assembly (Parallel-Mounted)	1
6	51KG1-4	Sleeve and Adapter Assembly (Cross-Mounted)	1
7	525K1	Thrust Bearing (.125" Thick)	2
8	33K23	Hand Chain Wheel	1
9	53A	Hand Chain (Specify Length)	1
10	H5527	Retaining Ring	1
11	45JG1G-1	Geared Wheel Assembly	2
12	102K11	Axle	2
13	45J1G	Geared Wheel	2
14	420K2	Gear	2
15	H5331	Pin	4
16	H2165	Screw	4
17	JF504-2	Ball Bearing	2
18	H5549	Retaining Ring	2
19	SK2658-6W	Retaining Ring	2
20	H4211	Washer (.125" Thick)	4
21	H3945	Nut	2

RECOMMENDED SPARE PARTS

To ensure continued service of your hoist, the following is a list of parts that are recommended to be kept on hand at all times to replace parts that have worn or failed. Parts applicable to your hoist should be stocked.

Part Name	Qty. Per Hoist
Brake Disc	1
Upper Hook Assembly	1
Lower Hook Assembly	1
Upper Latch	1
Lower Latch	1
Load Chain	

WARNING

Alterations or modifications of equipment and use of any parts other than COFFING EC manual hoist repair parts can lead to dangerous operation and injury.

TO AVOID INJURY:

Do not alter or modify equipment. Only use COFFING EC replacement parts.

NOTES

[illegible]

WARRANTY

LIMITATION OF WARRANTIES, REMEDIES AND DAMAGES

THE WARRANTY STATED BELOW IS GIVEN IN PLACE OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, NO PROMISE OR AFFIRMATION OF FACT MADE BY ANY AGENT OR REPRESENTATIVE OF SELLER SHALL CONSTITUTE A WARRANTY BY SELLER OR GIVE RISE TO ANY LIABILITY OR OBLIGATION.

Seller warrants that on the date of delivery to carrier the goods are free from defects in workmanship and materials.

SELLER'S SOLE OBLIGATION IN THE EVENT OF BREACH OF

WARRANTY OR CONTRACT OR FOR NEGLIGENCE OR OTHERWISE WITH RESPECT TO GOODS SOLD SHALL BE EXCLUSIVELY LIMITED TO REPAIR OR REPLACEMENT, F.O.B. SELLER'S POINT OF SHIPMENT, OF ANY PARTS WHICH SELLER DETERMINES TO HAVE BEEN DEFECTIVE or if Seller determines that such repair or replacement is not feasible, to a refund of the purchase price upon return of the goods to Seller.

Any action against Seller for breach of warranty, negligence or otherwise, must be commenced within one year after such cause of action occurs.

NO CLAIM AGAINST SELLER FOR ANY DEFECT IN THE GOODS SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE YEAR FROM THE DATE OF SHIPMENT. Seller shall not be liable for any damage, injury or loss arising out of the use of the goods if, prior to such damage, injury or loss, such goods are (1) damaged or misused following Seller's delivery to carrier; (2) not maintained, inspected, or used in compliance with applicable law and Seller's written instructions and recommendations; or (3) installed, repaired, altered or modified without compliance with such law, instructions or recommendations.

UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES AS THOSE TERMS ARE DEFINED IN SECTION 2-715 OF THE UNIFORM COMMERCIAL CODE.

INDEMNIFICATION AND SAFE OPERATION

Buyer shall comply with and require its employees to comply with directions set forth in instructions and manuals furnished by Seller and shall use and require its employees to follow such instructions and manuals and to use reasonable care in the use and maintenance of the goods. Buyer shall not remove or permit anyone to remove any warning or instruction signs on the goods. In the event of personal injury or damage to property or business arising from the use of the goods, Buyer shall within 48 hours thereafter give Seller written notice of such injury or damage. Buyer shall cooperate with Seller in investigating any such injury or damage and in the defense of any claims arising therefrom.

If Buyer fails to comply with this section or if any injury or damage is caused, in whole or in part, by Buyer's failure to comply with applicable federal or state safety requirements, Buyer shall indemnify and hold Seller harmless against any claims, loss or expense for injury or damage arising from the use of the goods.

CMCO Warranty (HOISTS)

A. Columbus McKinnon Corporation ("Seller") warrants to the original end user ("Buyer") that: (a) for a period of one (1) year from the date of Seller's delivery of the goods (collectively, the "Goods") to the carrier, the electrical components of the Goods will be free from defects in workmanship and materials; and (b) for the life of the Goods, the mechanical components of the Goods will be free from defects in workmanship and materials.

B. IN THE EVENT OF ANY BREACH OF SUCH WARRANTY, SELLER'S SOLE OBLIGATION SHALL BE EXCLUSIVELY LIMITED TO, AT THE OPTION OF SELLER, REPAIR OR REPLACEMENT, F.O.B. SELLER'S POINT OF SHIPMENT, OF ANY GOODS THAT SELLER DETERMINES TO HAVE BEEN DEFECTIVE OR, IF SELLER DETERMINES THAT SUCH REPAIR OR REPLACEMENT IS NOT FEASIBLE, TO A REFUND OF THE PURCHASE PRICE UPON RETURN OF THE GOODS TO SELLER. NO CLAIM AGAINST SELLER FOR ANY BREACH OF (i) SUCH WARRANTY WITH RESPECT TO THE ELECTRICAL COMPONENTS OF ANY GOOD SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE (1) YEAR FROM THE DATE OF SELLER'S DELIVERY TO THE CARRIER AND (ii) SUCH WARRANTY WITH RESPECT TO THE MECHANICAL COMPONENTS OF ANY GOOD SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE (1) YEAR FROM THE DATE THE DATE ANY ALLEGED CLAIM ACCRUES. EXCEPT FOR THE WARRANTY SET FORTH ABOVE, SELLER MAKES NO OTHER WARRANTIES WITH RESPECT TO THE GOODS, WHETHER EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUALITY AND/OR THOSE ARISING BY STATUTE OR OTHERWISE BY LAW OR FROM ANY COURSE OF DEALING OR USE OF TRADE, ALL OF WHICH ARE HEREBY EXPRESSLY DISCLAIMED.

C. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY THIRD PARTY WITH RESPECT TO ANY GOOD, WHETHER IN CONTRACT, TORT OR OTHER THEORY OF LAW, FOR LOSS OF PROFITS OR LOSS OF USE, OR FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, DIRECT OR INDIRECT DAMAGES, HOWSOEVER CAUSED. SELLER'S MAXIMUM LIABILITY TO BUYER WITH RESPECT TO THE GOODS SHALL IN NO EVENT EXCEED THE PRICE PAID BY BUYER FOR THE GOODS THAT ARE THE SUBJECT OF THE APPLICABLE CLAIM.

D. Seller shall not be liable for any damage, injury or loss arising out of the use of the Goods if, prior to such damage, injury or loss, such Goods are: (1) damaged or misused following Seller's delivery to the carrier; (2) not maintained, inspected, or used in compliance with applicable law and Seller's written instructions and recommendations; or (3) installed, repaired, altered or modified without compliance with such laws, instructions or recommendations.

E. This warranty is limited and provided only to the original end user. **Each Good must be registered within sixty (60) days of receipt of each product to establish eligibility.** Please register at www.cmworks.com/hoist-warranty-registration or submit registration card via US mail.

F. Any action against Seller for breach of warranty, negligence or otherwise in connection with the electrical components of any Good must be commenced by Buyer within one (1) year after: (a) the date any alleged claim accrues; or (b) the date of delivery of the Goods to Buyer, whichever is earlier. Any action against Seller for breach of warranty, negligence or otherwise in connection with the mechanical components of any Good must be commenced by Buyer within one (1) year after the date any alleged claim accrues.

WARNING

Alterations or modifications of equipment and use of non-factory repair parts can lead to dangerous operation and injury.

TO AVOID INJURY:

- Do not alter or modify equipment.
- Do use only factory replacement parts.



USA: Ph: (800) 888.0985 • (716) 689.5400 • Fax: (716) 689.5644

CANADA: Ph: (877) 264.6478 • Fax: (877) 264.6477



© 2016 Columbus McKinnon Corporation. All Rights Reserved.

P/N EC680-7 April 2017
Order # 5041558-0 & 5041679-0